

NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION (PATCHING FIRST)

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE WITH CLASS C OR D PATCH.
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

SEQUENCE OF CONSTRUCTION (MILLING FIRST)

- 1. MILL HMA FIRST IF THERE IS AT LEAST 4/2 INCHES OR MORE OF HMA MATERIAL ON TOP OF THE EXISTING PAVEMENT OR IF THE PAVEMENT IS FULL DEPTH HMA. A MINIMUM OF 2 INCHES OF HMA MATERIAL SHALL BE IN PLACE AFTER MILLING.
- 2. REMOVE AND REPLACE WITH FULL DEPTH CLASS D PATCHES TO TOP OF MILLED SURFACE.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS

NAME	DATE	ILLINOIS DEPARTMENT	OF TRANSF
. SHAH	01/14/95		
. SHAH	03/23/95		
. SHAH	04/24/95	PAVEMENT PA	TCHING
. HOUSEH	03/15/96	HMA SURFACED	
. ABBAS	03/21/97		
. ABBAS	01/20/98	PAVEN	1ENT
RT ABBAS	04/27/98		
. BORO	01/01/07	SCALE: VERT. NONE	
POPO	09/04/07	SCALE: HODIZ NUNE	DRAI

CHECKED BY BD400-04 (BD-22)

FOR

DATE VAME SCALE NAME